



INSTRUCTIONS FOR USE

Thank you for purchasing a RACER heating jacket. Please read these instructions carefully to avoid damage to your heating jacket or its improper use.

CONTENTS OF THE PACKAGE

- 1 RACER heated jacket
- 1 Rechargeable Power Bank
- 1 Charging cable


DESCRIPTION OF THE JACKET

Functional heated jacket designed for daily use. Quilted product in water-repellent nylon, closed by a central zip, 2 outside pockets and 2 inside pockets for the men's model. Comfort: 3 heating levels with individual heat adjustment. The 4 heating zones are located on the front and back of the jacket.

STRUCTURE OF THE HEATING SYSTEM

The system consists of two heating panels with graphene technology, a powerbank and a charging cable.

HEATING SYSTEM DIAGRAM



TECHNICAL CHARACTERISTICS

- Voltage of the power bank : 5V 3A
- Autonomy of the power bank : 3h to 7 hours depending on the conditions of use
- Dimension and weight of the power bank :
136.8mm x 68.5mm x 15.5mm, 218g

WARNING: Battery life may vary depending on the heating intensity on which the gloves are used. The variations of outside temperature as well as the rate of humidity can also impact the autonomy of the batteries.

BATTERY CHARGING

- The jacket is supplied with a power bank PB010-B 10 000 MAH
- For all modalities of use and loading, please refer to the power bank's manual

CAUTION: Do not charge if the power bank or charger is damaged or wet.

CAUTION: Use only the supplied charger to charge the power bank.

Directions for use:

- It is advisable to charge the power bank before the first use.
- It is advisable to recharge the batteries after each use afin order to keep the gloves always ready for use.

GENERAL OPERATION

- Turn on the power bank with a 3 second push on the side switch
- Connect the plug of the heating panels 2 to the socket of the power bank 3
- Insert the power bank into the pocket 1
- To turn on the system, press the switch 5 for 3 seconds.

The heating system has three power settings: high to low. The power level is indicated by LEDs on the switch as shown in the table on the right.

OPERATION OF THE BUTTON

SWITCH	FUNCTION	LED
LONG PRESS (3 SEC.)	POWER ON FULL POWER	
SHORT PRESS	HIGH POWER	
SHORT PRESS	MEDIUM POWER	
SHORT PRESS	MINIMUM POWER	
LONG PRESS (3 SEC.)	SYSTEM OFF	

Once the system is turned on, each short press causes a power change.

LIFE OF THE POWER BANK

The battery is a consumable product. It will gradually lose its charging capacity after repeated use and after a certain period of time. If the battery's useful life becomes extremely short, the battery will likely reach the end of its life and you will need to purchase a new one. Battery life will vary depending on various factors such as storage conditions, usage conditions, environment, and the characteristics of the battery pack.

MAINTENANCE AND STORAGE OF THE POWER BANK

To preserve your batteries and increase their life, be sure to follow these tips:

- It is recommended that you do not discharge the batteries completely.
- Be sure to store batteries in a cool place between 5°C/48°F and 20°C/61°F.
- Batteries should not be connected to the glove or charger during storage.

CAUTION: Extended periods of non-use will damage the batteries.

When not in use for more than 2 months, it is imperative to store the power bank (unplugged) with a charge level between 50% and 75%. During this period, please check the charge level of the power bank and if necessary perform a charge cycle.

MAINTENANCE

The jacket can be cleaned with a mild soap and a damp cloth.

- Do not machine wash
- Do not tumble dry
- Do not dry clean
- Do not use bleach or fabric softener.

When the jacket is not in use, unplug the power bank and store it in a dry place.

Reference : DISTRICT MEN / DISTRICT WOMEN

RACER SAS - 1 RUE DE LA FORGE - 13300 SALON DE PROVENCE - FRANCE
RACERGLOVES.COM

WARNING

Misuse of this product or failure to follow instructions may result in overheating, fire or burns. Be sure to follow all instructions.

1. Do not use the system if any of the cables are worn or damaged.
2. Do not cut or pierce the heating jacket.
3. Never use this system with an infant, child, incapacitated person, anyone who is insensitive to heat, or anyone who cannot fully understand the instructions.
4. Do not use this system if you have a medical pacing device.
5. Do not attempt to open the battery or attempt to remove the battery cover.
6. Do not use the power bank if it is wet or if it has changed shape.
7. Do not use the system if the environment is saturated with moisture or if you are immersed in water.
8. Do not use the system to dry the jacket.
9. Do not use the jacket when it is wrinkled, rolled or folded.
10. Do not sleep with the heated jacket in operation.
11. Do not place any heat source on the jacket (heater, hair dryer...).
12. Do not place large or heavy objects on the jacket, such as a suitcase.
13. Do not fold the heated jacket while it is still hot.